





VESA Apollo Keyway Lock Install Instructions

Apollo4 pole 	Keyway VESA 
Thin client (not supplied) 	Keyway Stop 

Step 2: Slide Keyway VESA on to the pole.



Step 3: Tighten the screw inside the Keyway VESA with the supplied allen key.



Step 4: Reattach the top cap. Screw the thin client into the VESA.



If thin client can be attached when the VESA is installed.

Step 2: Slide the Keyway Stop on to the pole.



Step 3: Tighten the screw inside the Keyway Stop with the supplied allen key.



Step 4: Attach the thin client to the Keyway VESA assembly.



Step 5: Slide the thin client on to the pole until it rests on top of the Keyway Stop.



Step 6: Reattach the top cap to the pole.



Step 1: Remove top cap from pole



If thin client can not be attached when the VESA is installed.